

Manifold absolute pressure (MAP) sensor

Component disconnected

Fig. 81891

| Terminals | Condition   | Typical value | Note |
|-----------|-------------|---------------|------|
| 1 & earth | Ignition ON | 5 V           | 2    |

Notes

- 2. Checking supply voltage.

